

1500 Bar Instructions



1

Gather all components together; bars at the required length, corner pieces, corner pins, glue, your print, a trimming tool and, if appropriate, a centre brace bar and corner tabs.



2

Remove the release liner covering the tape.



3

Insert the bar into the corner piece.



4

Building the shape of the frame.



5

Turn the frame upside down.



6

Align with the back of your print using the notches in the corners sections as a guide.



7

Apply pressure through the holes in the corner pieces to secure the bars to the back of your print.



8

Lift off each corner piece and store for future use.



9

Use a knife or the GOframe trimming tool to trim around the edges of your canvas.



10

Trim diagonally across each corner.



11

Trim into each corner at an angle of approximately 45°, creating tabs at the end of each bar.



12

Apply a thin bead of glue under the edge of each bar.

1500 Bar Instructions



13

Fold up each tab created earlier and secure to the end of each bar.



14

Lift up each bar to create the canvas edge.



15

Insert a U-shaped pin into the pre drilled holes at each corner, apply pressure to secure the corner in place.



16

For larger frames you will need to slot the corner tabs into the pre cut slots and possibly insert a centre brace bar for additional tension.



Turn Canvases Into Collages with Collage Clips from GOframe, visit www.innovaart.com for more details



Distributed
by Innova
www.innovaart.com

Watch the video on the Innova Art YouTube channel